

EWIKON



pro CONTROL BASIC

Hot runner controllers

Operating manual

Table of contents

List of Figures	4
1 Introduction.....	5
1.1 Symbols used:	5
1.2 Notations	5
2 Safety instructions	5
2.1 Intended use	5
2.2 Information for operators and users	5
3 Structure and functionality	6
3.1 General information	6
3.2 Structure	6
3.2.1 Pro CONTROL BASIC 2, 6 and 12	7
3.2.2 Operating front	7
3.2.3 LED-strip	7
3.2.4 Power card	8
3.2.5 Fuses	8
3.2.6 Notification contact / Digital input	8
3.2.7 Identification on the controller	8
3.2.8 Wiring of the plug systems	9
4 Commissioning.....	10
4.1 Electrical connection	10
4.1.1 Mains power supply	10
4.1.2 Mains connection	10
4.1.3 Connection of the mould	10
4.2 Operating and display elements	11
4.2.1 Display elements	12
4.2.1.1 Status display.....	12
4.2.1.2 Zone display.....	12
4.2.2 Operating elements	13
4.2.2.1 Main switch	13
4.2.2.2 Soft keys	13
5 Operation	15
5.1 Zone selection	15
5.1.1 Selecting a zone	15
5.1.2 Selecting multiple zones	15
5.1.3 Selecting several consecutive zones	15
5.1.4 Selection of all zones	16
5.2 Operating mode	16
5.3 Setpoints	17
5.4 Output rate	18
5.5 Controller outputs	18
5.6 Parameter	19
5.6.1 Zone parameter	19
5.6.2 System parameter	20
5.7 Boost	21
5.8 Standby	21
6 Warning and error messages.....	22
6.1 Warnings	22
6.2 Alarms	23



7	Functions and parameterization.....	26
7.1	Basic settings	26
7.1.1	Access authorizations	26
7.1.2	Fahrenheit display	27
7.1.3	7.1.3 Thermocouple type	27
7.2	Control behavior	28
7.2.1	Control parameters P I D	28
7.2.2	Output level	28
7.2.3	Maximal output level	28
7.3	Heating	29
7.3.1	Softstart (Gentle heating)	29
7.3.2	Compound heating	29
7.4	Hot runner monitoring	30
7.4.1	Temperature monitoring	30
7.4.2	Average output level	32
7.4.3	Broken sensor	32
7.4.4	Heating current monitoring	32
7.4.5	Triac monitoring	33
7.5	Special functions	33
7.5.1	BOOST	33
7.5.2	STANDBY	34
7.5.3	Load detection	34
7.5.4	Default parameter	34
8	Parameter overview.....	35
8.1	Zone parameter	35
8.2	System parameter	36
9	Technical data.....	37
10	Spare parts + accessories.....	38
11	Appendix.....	39
11.1	Terminal bridges of the star-delta supply	39
11.1.1	Terminal jumpers in star network (state at delivery!)	39
11.1.2	11.1.2 Terminal bridges in delta network	39
11.2	Notification contact / Digital input	40

List of Figures

Figure 1 – pro CONTROL BASIC front panel	7
Figure 2 – Type label	8
Figure 3 – Wiring of plug systems	9
Figure 4 – Operating and display elements	11
Figure 5 – Zone display	12
Figure 5 – Temperature monitoring	31
Figure 6 - Star-network	39
Figure 7 - Delta-network	39


1 Introduction

1.1 Symbols used:


	Caution/Warning	Information on possible damage to property or personal injury
	Information	Important information

1.2 Notations

Menu structures between words are indicated by the > symbol and depicted in the same way on the device.

Interaction with the operator is denoted by the finger symbol. 

2 Safety instructions

	Please read this document completely and carefully before commissioning or operating the device.
---	--

2.1 Intended use

The hot runner controller is used to control the temperature of heating circuits and is designed for use under precisely defined conditions, such as supply voltage and temperature. The operator must therefore ensure that the controller is only used under operating conditions that comply with the technical data. The manufacturer is not liable for damage resulting from non-compliance with the intended use.

The hot runner controller is not suitable for use beyond the limits defined in the technical data and during its design. In addition, the use of spare parts from third parties and the implementation of non-described maintenance activities constitute failure to comply with the intended use.

Alterations, conversions and other modifications are made exclusively at the operator's own risk and could pose safety hazards. The manufacturer and distributor of this device cannot be held liable for direct and indirect damage resulting from improper handling or treatment.

2.2 Information for operators and users

The controllers are operated on the low-voltage network. The relevant safety regulations must be observed when connecting up the controller and performing maintenance on it. In addition, the local and general safety regulations must be observed for its installation and operation. The operator is responsible for compliance with these regulations. The operator must additionally make this documentation available to the user and provide instruction in the correct operation of the device. The user must be familiar with this documentation. In order to ensure reliable and safe operation, the individual user is required to observe the information and warnings.

The controllers may only be brought into operation by authorized specialist personnel. Under the terms of these operating instructions, specialist personnel are persons who can recognize and assess the dangers associated with the work entrusted to them on the basis of their specialist training, their experience and their knowledge of standards.

The device is checked carefully prior to delivery and has passed the tests specified in the test plan for its production, in conformity with the manufacturer's valid quality guidelines. To prevent any damage to the controller, it must be transported and stored in the correct manner. Further safety-related notices are marked in the individual sections of this documentation.

3 Structure and functionality

3.1 General information

The pro CONTROL BASIC hot runner controllers are especially suited to the temperature control of hot runner molds on injection molding machines. In use, the controllers are connected directly to the mold via cables.

During operation, the hot runner controllers deliver electric current to the heating units for an injection mold. The so-called heating current leads to an adjustable temperature increase in the heating units and hence in the mold. Continuous temperature monitoring takes place in parallel via connected thermocouples. In the event of deviations between the actual temperature recorded and the temperature set on the hot runner controller, the heating current is automatically adjusted until the two temperatures are identical.

The controllers are available in different variants. These differ solely in terms of the number of control circuits that are possible – which are also referred to as heating zones. Depending on the variant, hot runner controllers are available with 2 to 12 heating zones (in steps of 2).

3.2 Structure

Housing front: The pro CONTROL BASIC hot runner controller is operated from the housing front. In addition to the main switch for switching on and off, the controllers have 12 keys for convenient operation. Furthermore, the front contains all visualization elements. The setpoint and actual values of the individual zones are displayed via 7-segment displays. If required, the display can be switched over to heating current and output rate. In addition, status LEDs provide information about operating modes and messages of the individual zones. The controller status is visualized in color via a led strip visible from afar. In control mode, without a current error or warning message, this display lights up green. In case of a warning or alarm, the display changes to yellow or red (traffic light status). This allows a quick assessment of the controller status even from a distance. A detailed description of the display and operating functions can be found in chapters 4.2 and 5.

Back of housing: All connections are located on the back of the housing. In addition to the connecting cable, which is used for connection to the supply voltage, the controllers offer a further connection for a potential-free alarm contact and a 24V digital input for external control of the set-back operation. The connection to the hot-runner mold is established via plug-in systems.

3.2.1 Pro CONTROL BASIC 2, 6 and 12




Figure 1 – pro CONTROL BASIC front panel

3.2.2 Operating front

The convenient operation of the pro CONTROL BASIC hot runner controller is carried out on the front panel (Figure 1) via 12 keys. The front also contains all visualization elements. The setpoints and actual values of the individual zones are displayed via 7-segment displays. If required, the display can be switched over to heating current and output level.

3.2.3 LED-strip

The status of the controller is displayed in color via a strip of LEDs visible from afar. This enables a quick assessment of the current controller or tool status.

3.2.4 Power card

Inside the housing there are power cards which control connected heaters and record measured temperatures of the thermocouples. Each zone is switched individually via relays on the power cards, so that individual zones can be switched off separately and a seamless production process is always guaranteed.

3.2.5 Fuses

The controllers have three different types of fuses inside the housing. Each zone has two fuses on the power card. One fuse is used to protect the load output (fuse in the fuse holder below the heat sink). The second fuse, on the other hand, is required for use in delta networks. In addition, another control fuse is located in a terminal on the bottom of the housing.

3.2.6 Notification contact / Digital input

The pro CONTROL BASIC hot runner controllers have a potential-free message contact and a digital control input, which are brought out via a 7-pin plug on the rear of the unit. A contact diagram of the built-in plug is given in chapter 11.2.

The control input is PLC-compatible, i.e. it operates over a voltage range of 13...30 VDC with a typical current consumption of approx. 8.5 mA. The controller can be switched to standby mode via the input. The controller remains in this mode as long as the signal is present. Deactivation via the standby button on the device is not possible.

The potential-free notification contact is used to transmit the controller status to an injection molding machine. When warnings or alarms occur, the contact opens. Accordingly, the contact is normally closed (NC) and opens as soon as an alarm or warning is present. Chapter 6 provides an overview of the behavior when messages occur.

3.2.7 Identification on the controller

The type label is mounted on the side of the controller housing. It contains the type designation with the number of zones, the electrical connection data and the manufacturer's data.


Typ / Type		Pro Control Basic 6	
S/N	2009	Prod. KW /	03 / 2020
	1	CW	
Code	E7H1-AKB4-C1Z6-87A		
Versorgung / Supply	<ul style="list-style-type: none"> ● Y 230/400 VAC 50/60 Hz ○ Δ 230 VAC 50/60 Hz 		
Belastung / Load	3x 16 A		
Schutzart / IP Class	IP20		
Temp. Fühler / Sensor	Fe-CuNi Type J		
EWIKON Heißkanalsysteme GmbH		Made in Germany 	
Meldebuchse / Message Socket			
Pin 1+3	Relay	Sammelmeldung / collective message	
Pin 2+6		Steuereingang / Digital input	

Figure 2 – Type label

3.2.8 Wiring of the plug systems

The plugs for connecting the temperature sensors and heating elements to a hot runner are available on the rear of the controller. The customer-specific wiring plan for the plug systems is located on the side of the controller housing (see Figure 3 for an example).


Zone	Sensor X1		Load X1	
	+	-	N	230V
1	13	14	2	1
2	15	16	4	3
3	17	18	6	5
4	19	20	8	7
5	21	22	10	9
6	23	24	12	11

Zone	Sensor X2		Load X2	
	+	-	N	230V
7	13	14	2	1
8	15	16	4	3
9	17	18	6	5
10	19	20	8	7
11	21	22	10	9
12	23	24	12	11

Figure 3 – Wiring of plug systems

4 Commissioning

4.1 Electrical connection

	<p>Important! Before the device is connected to the supply voltage, a check must first be performed to ensure that the mains electricity conditions comply with the specifications on the type plate.</p>
	<p>The electrical connections must be performed by a qualified electrician. Commissioning and operation while the controller is running are only to be carried out by authorized qualified personnel!</p>
	<p>Switching off all the outputs or individual zones will not protect any of the outputs against hazardous voltages. Before working on the connected heating elements, the associated connections must be unplugged, or the entire device disconnected from the mains power.</p> <p>Before the device is opened, it must be disconnected from the mains power!</p>

4.1.1 Mains power supply



Before connecting the device to the supply voltage, a check must be conducted to ensure that the mains electricity system is correct. The hot runner controllers are prepared by default for operation in a star network (3x400VAC + N + PE) but can also be operated in a triangular network (3x230VAC + PE). For operation in a triangular network without a neutral conductor, it is essential to follow the local regulations for the installation of electrical systems. The terminals in the controller must be bridged accordingly for use in a star or triangular network. Annex 11.1 contains a clear terminal connection diagram.

4.1.2 Mains connection

To ensure correct operation, the hot-runner controller is connected to the low-voltage mains by using the connecting cable connected to the unit.

4.1.3 Connection of the mould

To connect the individual control zones to the corresponding injection mold, use must be made of appropriate leads for the sensor and heating unit connection.

	<p>Please note: it must always be ensured that the internal wiring, the wiring of the cable set and the wiring in the mold are suitably coordinated with each other.</p>
	<p>Important! To exclude any effects of potential shifts, the injection molds that are connected up must be properly earthed in all cases.</p>

4.2 Operating and display elements

The operation as well as all display elements of the hot runner controllers is carried out via the soft keys on the front of the housing. The following illustration shows the front view of a 6-zone controller, from which all operating and display elements are shown.







Figure 4 – Operating and display elements

4.2.1 Display elements

4.2.1.1 Status display

The status of the controller is indicated by a LED strip in the front. In control mode, this indicator lights up green. In case of a warning or alarm, the display changes to yellow or red (traffic light status).

	Green signals all is well. The controller operates in normal mode.
	Yellow indicates warning messages that indicate a deviation from the normal state.
	Red indicates alarms. Depending on the fault, outputs of corresponding zones are also deactivated.

4.2.1.2 Zone display

Each heating zone has two 7-segment displays and four LEDs for status indication. The 7-segment displays show either the setpoint and actual value or the heating current and degree of operation. In addition, the four LEDs can also be used to display the states shown below.




Figure 5 – Zone display









4.2.2 Operating elements

4.2.2.1 Main switch





The main switch is located on the back of the housing. The switch must be operated to switch the controller on and off.

4.2.2.2 Soft keys

Operating element	Description
<p style="text-align: center;">ZONE / SELECT</p> 	<p>Selection of zones</p> <p>Each time the arrow keys are pressed, the display jumps one zone further.</p>
<p style="text-align: center;">VALUE</p> 	<p>Change in value</p>
	<p>Confirm button / Acknowledge error</p>
	<p>Boost</p>
	<p>Standby</p>
	<p>Change operating mode</p>
	<p>Parameterization / System information</p>
	<p>Basic view: Display of all zones / Reject input</p>

Shift key for the zone display

Display: actual value (ACT) and setpoint (SET)



Display: Current (I[A]) and output level (Y[%])



Activating / deactivating the controller outputs




Temperature unit of the display



5 Operation

5.1 Zone selection





5.1.1 Selecting a zone

Step	Operation	Description
1.		<p>Each time the arrow keys are pressed, the display jumps one zone further.</p> <p>All other zones that are not selected are hidden.</p>


5.1.2 Selecting multiple zones

Step	Operation	Description
1.		Select zone
2.		Press confirmation key
	... repeat 1. and 2.	To select any zones





5.1.3 Selecting several consecutive zones

Step	Operation	Description
1.		Selection of the 1st zone to be selected
2.		Keep confirmation key pressed
3.		With each keystroke a zone is added to the selection
4.		Release the confirmation key





5.1.4 Selection of all zones

Step	Operation	Description
1.		The basic rule is: In the basic view, all zones can be operated and are virtually already selected for a value change. "The Zones that you see can also be operated."








5.2 Operating mode

Step	Operation	Description
1.		Select the zone(s) as described in 5.1
2.		Selection of the operating mode The display switches between Manual mode <i>Hand</i> Control mode <i>on</i> Zone off <i>off</i> Note: The display flashes and must be confirmed within 5 seconds.
3.		Confirm the entry The display stops flashing
4.		Press the Home button to return to the overall display of all zones.


5.3 Setpoints

Step	Operation	Description
1.	<p style="text-align: center;">ZONE / SELECT</p> 	Select the zone(s) as described in 5.1
2.	<p style="text-align: center;">VALUE</p> 	Use the buttons to set the setpoint to the desired value. The display flashes, indicating that the value has not yet been accepted.
3.		Confirm the entry The display stops flashing
4.		Press the Home button to return to the overall display of all zones.

5.4 Output rate








Step	Operation	Description
1.	<p style="text-align: center;">ZONE / SELECT</p> 	Select the zone(s) as described in 5.1
2.		<p>Selection of the operating mode.</p> <p>Operate until manual mode <i>Hand</i> is displayed.</p>
3.		Confirm selection
4.		Switching the zone display to Current (I) and output rate (Y)
5.	<p style="text-align: center;">VALUE</p> 	<p>Use the buttons to set the output level to the desired value.</p> <p>The display flashes, indicating that the value has not yet been accepted.</p>
6.		<p>Confirm the entry.</p> <p>The display stops flashing.</p>
7.		Press the Home button to return to the overall display of all zones.

5.5 Controller outputs










Step	Operation	Description
1.		Activating / deactivating the controller outputs either switches on all heating zones in control mode and manual operation or switches off all zones.

5.6 Parameter



5.6.1 Zone parameter

Step	Operation	Description
1.	<p>ZONE / SELECT</p> 	Select the zone(s) as described in 5.1
2.		Press key to change to the parameterization level
3.	<p>ZONE / SELECT</p>  	<p>Select parameter. Each time the arrow keys are pressed, the parameter is incremented or decremented.</p>
4.	<p>VALUE</p> 	<p>Use the buttons to set the value of the selected parameter to the desired value.</p> <p>Note! Password entry required before parameterization (default "22"). Set the current password with the keys and confirm. The parameter can then be changed</p> <p>The display flashes. This means that the value has not yet been accepted.</p>
5.		<p>Confirm the entry. The display stops flashing.</p>
6.		Press the Home button to return to the overall display of all zones.


5.6.2 System parameter

Step	Operation	Description
1.	 ... 2s	<p>Press and hold for 2s. The display changes to the system parameter level.</p> <p>This level contains system information that cannot be changed:</p> <div style="display: flex; align-items: center;">  <p>System Information</p> </div> <p>However system parameters and system functions can be changed. The representation is made as <i>SYS PAR</i> or <i>SYS Fun</i>:</p> <div style="display: flex; align-items: center;">  <p>System Parameter</p> </div> <div style="display: flex; align-items: center;">  <p>System Function</p> </div>
2.	<p style="text-align: center;">ZONE / SELECT</p> 	<p>Select system parameters.</p>
3.	<p style="text-align: center;">VALUE</p> 	<p>Set the value of the selected parameter to the desired value using the arrow keys.</p> <p>Note! Password entry required before parameterization (default "22"). To do this, set the current password with the keys and confirm. The parameter can then be changed</p> <p>The display flashes, indicating that the value has not yet been accepted.</p> <p>Example: System parameter <i>HH</i> with value 500</p> <div style="display: flex; align-items: center;">  </div>
4.		<p>Confirm the entry. The display stops flashing.</p>
5.		<p>Press the Home button to return to the overall display of all zones.</p>

5.7 Boost

Step	Operation	Description
1.		Select the zone(s) as described in 5.1
2.		<p>Pressing the Boost button increases the setpoint value for the selected zones by the value stored in the zone parameters.</p> <p>The duration of the boost process is stored in parameters.</p> <p>If necessary, the standby mode is ended by the boost.</p>

5.8 Standby

Step	Operation	Description
1.		<p>Pressing the standby button lowers the setpoint to the value stored in zone parameters.</p> <p>Confirming again deactivates the standby mode.</p> <p>The standby mode terminates the boosting if necessary.</p> <p>The standby mode can also be activated via the digital 24V control input.</p>

6 Warning and error messages

The pro CONTROL BASIC controllers provide information about the current status via status and 7-segment display. Warnings and alarms are shown as abbreviations in the 7-segment display. In addition, the LED band indicates the controller status in green, yellow and red. In the standard state, the LED band lights up green. An existing warning is displayed in yellow. Warning messages alert the plant operator to possible problems. However, production operation is continued. A suddenly occurring alarm is displayed in red. If it occurs, the plant operator must intervene. For critical alarms, an error acknowledgement or a device restart may be necessary. The following subchapters contain a detailed list of all warnings and alarms.

6.1 Warnings

Warnings are shown in yellow  by the status display (LED stripe).

7 segm. display	• Description / Causes	Notification contact
dH	Positive temperature deviation <ul style="list-style-type: none"> • The actual value of the sensor is above the tolerance band set as zone parameter <i>P03</i>. 	Warning is displayed
	<ul style="list-style-type: none"> - Tolerance band (zone parameter <i>P03</i>) too small, if oscillation occurs due to the process. 	
dL	Negative temperature deviation <ul style="list-style-type: none"> • The actual value of the sensor is below the tolerance band set as zone parameter <i>P03</i>. 	Warning is displayed
	<ul style="list-style-type: none"> - Controller is in the heat-up phase - Tolerance band (zone parameter <i>P03</i>) too small - Heat output may not be sufficient - Heating could be defective - Sensor not in contact with this zone 	
-E-	Broken sensor <ul style="list-style-type: none"> • No connection to the sensor. 	Warning is not displayed
	<ul style="list-style-type: none"> - No sensor connected - Sensor cables / connecting cable defective - Sensor plug connections defective <p>Zone operates with the average output level in manual mode</p>	

6.2 Alarms

Alarms are shown in red ■■■■ by the status display (LED stripe).

7 segm. display	Description / Causes	Notification contact
HH	<p>Shut-off temperature</p> <ul style="list-style-type: none"> • - The actual value of the sensor is above the maximum permissible temperature (system parameter <i>HH</i>). • All outputs are switched off. The controller can only be restarted by restarting or acknowledging the error by . The actual value must also be below the parameter <i>HH</i>. 	Alarm is displayed
	<ul style="list-style-type: none"> - Setpoint too close to <i>HH</i> value - Triac malfunction. This results in current flowing and heating without output level 	
H_i	<p>Over temperature</p> <ul style="list-style-type: none"> • The measured actual value of the sensor is greater than the limit value set under Zone parameter <i>P02</i> (Hi-Alarm). • The corresponding zone is switched off until the actual value falls below the value of the parameter <i>P02</i> again. 	Alarm is displayed
	<ul style="list-style-type: none"> - Alarm limit (zone parameter <i>P02</i>) is too close to the setpoint - Triac malfunction. This results in current flowing and heating without output level 	
Lo	<p>Under temperature</p> <ul style="list-style-type: none"> • The actual value of the sensor is below the limit value set under zone parameter <i>P01</i> (Lo alarm). 	Alarm is displayed
	<ul style="list-style-type: none"> - Alarm limit (zone parameter <i>P01</i>) is too close to the setpoint - Heat output may not be sufficient - Heating could be defective - Sensor not in contact with this zone - Sensor polarity reversal - Controller is heating up 	

7 segm. display	• Description / Causes	Notification contact
-E-	Broken sensor <ul style="list-style-type: none"> • No connection to the sensor, in addition the average output level could not yet be recorded. 	Alarm is displayed
	<ul style="list-style-type: none"> - No sensor connected - Sensor cables / connecting cable defective - Sensor plug connections defective 	
Pol	Sensor polarity <ul style="list-style-type: none"> • The polarity of the sensor is reversed • Due to incorrect polarity, negative temperature values can be measured by the controller. Therefore, the corresponding zone is switched off at -15°C and can only be switched on again after the polarity has been changed. 	Alarm is displayed
	<ul style="list-style-type: none"> - Sensor wrong polarity. This causes the measured temperature to show falling values during heating. 	
IFU	Fuse <ul style="list-style-type: none"> • Zone is not supplied with power 	Alarm is displayed
	<ul style="list-style-type: none"> - Fuse defective 	
Itr	Triac <ul style="list-style-type: none"> • Without control of the outputs a current flow 	Alarm is displayed
	<ul style="list-style-type: none"> - - Triac defective, switches through permanently <p>Note: The relevant zone is switched off and the alarm output opens. After exchanging the triac, the controller can be operated again.</p>	
Pot	Sensor voltage <ul style="list-style-type: none"> • The voltage potential on the sensor cable is impermissibly high 	Alarm is displayed
	<ul style="list-style-type: none"> - Wiring error - Cable or plug defective - Cable pinching 	

7 segm. display	• Description / Causes	Notification contact
noI	No current flow <ul style="list-style-type: none"> • When controlling the outputs with a output level > 0% no current flows 	Alarm is displayed
	<ul style="list-style-type: none"> - Cable or plug defective - Heating defective - Triac defective, does not switch through - No heating connected 	
rEL	Relay <ul style="list-style-type: none"> • Internal hardware error - Output relay of the zone defective • Message must be acknowledged 	Alarm is displayed
	<ul style="list-style-type: none"> - Defect of the device hardware 	
di	Current deviation <ul style="list-style-type: none"> • The rated current set in zone parameter P14 deviates from the current monitoring tolerance set in zone parameter P15. 	Alarm is displayed
	<ul style="list-style-type: none"> - Heating defective or partially failed - Correct rated current set under zone parameter P14 ? 	
	<ul style="list-style-type: none"> - Tolerance band (zone parameter P15) too small 	
IH1	Load short circuit <ul style="list-style-type: none"> • An impermissibly high current flows through a short circuit in the heating circuit • Message must be acknowledged 	Alarm is displayed
	<ul style="list-style-type: none"> - Wiring error - Cable or plug defective - Line pinch 	
CAN	CAN-Bus fault <ul style="list-style-type: none"> • - Communication error of the internal power card 	Alarm is displayed
	<ul style="list-style-type: none"> - Identical address assigned twice - Cable not connected correctly - Missing final resistance of the last participant 	

7 Functions and parameterization

7.1 Basic settings

(See chapter 5.6.2 System parameter)

7.1.1 Access authorizations

Description

System parameter Cod : Password

The control unit is protected against unauthorized settings by a password = identification code Cod . The password can be individualized after it has been entered.

**The release is done
with code "22"**

System parameter idL : User level

The idL parameter determines the degree of locking, with which the device is locked against inputs.

0= No interlock

1= Only setpoints and operating modes free

2= All parameters locked

idL is always only accessible via the code

System parameter Pin : Pin Code

If the password Cod has been changed and is subsequently unknown, the password can be reset via the parameter Pin . A master password must be generated by the manufacturer via the pin shown.

Parameter

System parameter

Settings

Cod ID Code

0...999, Default value = 22

idL ID Level

0...2, Default value = 1

Pin ID Pin Code

(Read only, value cannot be changed)

7.1.2 Fahrenheit display

Description	This parameter indicates the temperature unit in which the controller is displayed and operated. During operation, the setting can also be read off via LED indicators on the display.	
	<ul style="list-style-type: none"> • 0: °C • 1: °F 	
Parameter	System parameter <i>FAH</i> Fahrenheit-display	Settings 0 / 1, Default value = 0 → °C

7.1.3 Thermocouple type

Description	The <i>tEt</i> parameter specifies the type of thermocouples used for the entire controller.	
Parameter	System parameter <i>tEt</i> Thermocouple type	Settings 0: Fe/CuNi Typ J 1: Ni/CrNi Typ K with temperature range max. 800°C Default value = 0

7.2 Control behavior

7.2.1 Control parameters P I D

Description	<p>The automatic determination of the control parameters P I D is called classification. It is performed automatically after the controller outputs are switched on and overwrites all previous settings of the control parameters.</p> <p>PID-Parameter When classifying the zones, the controller sends a defined heating impulse to each zone in order to automatically determine the heating behavior of e.g. the nozzle or manifold. The controller determines the suitable control parameters for P, I and D and stores them in the parameters <i>P04</i>, <i>P05</i> and <i>P06</i>.</p> <p>The process can be recognized by the flashing green LED band and can take up to 60s for large, sluggish objects. The determined classification can be viewed for each zone under Parameter <i>02</i>.</p> <p>Activate and deactivate classification To obtain special settings of the P, I and D parameters in any case, the classification per zone can be switched off with the parameter <i>P07</i> = "0".</p>	
-------------	--	--

Parameter	Zone parameters	Settings
<i>P04</i>	P-Band	0...100%
<i>P05</i>	Tn Reset time	0...999s
<i>P06</i>	Tv Derivative time	0...999s
<i>P07</i>	Activate classification	OFF = 0 ON = 1 Default value = 1
<i>02</i>	Classification of the zone	Read only

7.2.2 Output level

Description	<p>The parameter specifies the output level for manual operation. If the controller is already in manual mode, the setting of <i>P13</i> can also be made as described in section 4.4.</p>	
-------------	--	--

Parameter	Zone parameters	Settings
<i>P13</i>	Output level	0...100% Default value: 0%

7.2.3 Maximal output level

Description	<p>This parameter limits the maximum output power of the heaters via the output level.</p>	
-------------	--	--

Parameter	Zone parameter	Settings
<i>P12</i>	Maximal output level	0...100% Default value: 100%

7.3 Heating

7.3.1 Softstart (Gentle heating)

Description	<p>All zones are gently heated separately to 100°C, independent of a higher setpoint temperature. Up to a temperature of 50°C, each zone is heated with a maximum degree of operation of 50%.</p> <p>From 50 - 100°C the degree of operation is determined according to the existing temperature, i.e. from 60°C with a degree of operation of 60% etc.</p> <p>After reaching 100°C, the soft start is completed and the zone can heat at full power.</p> <p>Softstart is already set at the factory.</p>	
Parameter	<p>Zone parameter</p> <p><i>P08</i> Softstart</p>	<p>Settings</p> <p>0: Without Softstart 1: With Softstart Default value: 1</p>

7.3.2 Compound heating

Description	<p>Joint heating with respect to the slowest zone</p> <p>This is to prevent the complete mold, manifold and nozzles from heating up with thermal imbalances.</p> <p>All zones are heated in such a way that they may only have a certain temperature difference to each other (system parameter Δt)</p> <p>The slowest zone (whose number can be read off as information in the system parameter SC) works with maximum output. The other zones are limited in the degree of operation in such a way that they may only advance by the set temperature difference. The parameter <i>P09</i> defines the assignment of a zone to the "compound".</p>	
Parameter	<p>Zone parameter</p> <p><i>P09</i> Compound heating</p> <hr/> <p>System parameter</p> <p>Δt Max temperature difference of the compound</p> <p>SC Slowest channel</p>	<p>Settings</p> <p>0: Zone without compound 1: Zone with compound</p> <hr/> <p>Settings</p> <p>Adjustable from 1° ... 100° Default value: 10°</p> <p>Read only</p>

Example

Zones 1 to 6 should be heated together. The temperature difference during the heating process should not exceed 20° C. Zones 7 and 8 should not be part of the heating compound. The settings:

Zone 1 to zone 6: Parameter *P09* = 1

Zone 7 and Zone 8: Parameter *P09* = 0

System parameter Δt = 20

7.4 Hot runner monitoring

7.4.1 Temperature monitoring

Description	<p>Monitoring of the zones for under- or overtemperature</p> <p>Limit value for undertemperature: Lo alarm If the process value is below this value, an alarm is given. The LED band lights up red and the alarm contact is switched.</p> <p>Limit value for overtemperature: Hi alarm: If the process value is above this value, the zone is switched off until the process value falls below the Hi-alarm again. The LED band lights up red and the alarm output is switched.</p> <p>Negative temperature deviation: dL tolerance band In case of a dL alarm, the process value deviates too much from the setpoint and is below the specified tolerance band. The LED band lights up yellow and the alarm output is switched. The zone is NOT switched off. The size of the tolerance band is set in parameter <i>P03</i>.</p> <p>Positive temperature deviation: dH- tolerance band In case of a dH alarm, the actual value deviates too much from the setpoint and is above the specified tolerance band. The LED band lights up yellow and the alarm output is switched. The zone is NOT switched off. The size of the tolerance band is set in parameter <i>P03</i>.</p> <p>Shut-off temperature: HH-Alarm The <i>HH</i> parameter defines the shut-off temperature of the device. If the -value is exceeded, an alarm is generated and all zones are switched off. The LED band lights up red.</p>
-------------	---

Parameter	Zone parameter	Settings
	<i>P01</i> Lo-Alarm	-15...600°C (800°C for NiCrNi as Thermocouple) Default value: 0°C
	<i>P02</i> Hi-Alarm	1...600°C (800°C for NiCrNi as Thermocouple) Default value: 400°C
	<i>P03</i> dL / dH Tolerance band	1...600°, Default value: 15°C
System parameter		
	<i>HH</i> HH-Alarm	0...600°C (800°C for NiCrNi as Thermocouple) Default value: 400°C

Example

The set point is 200°C.

Above and below the setpoint, a limit value should be set at intervals of 15°C.

A warning is to be issued when these limits are exceeded or undercut. The LED band lights up yellow and the alarm output switches.

If the temperature exceeds 250°C an alarm is to be triggered and the zone switched off.

The LED-band lights red and the alarm output switches.

If the temperature falls below 150°C an alarm should also be triggered. The LED band is red and the alarm output switches.

A value of 400°C should be set as the maximum upper temperature limit for all zones. If this value is exceeded, all zones are switched off.

The following settings must be made:

Parameter	Zone parameter	Settings
	<i>P01</i> Lo-Alarm	150°C
	<i>P02</i> Hi-Alarm	250°C
	<i>P03</i> dL / dH Tolerance band	15°C
System parameter		
	<i>HH</i> HH-Alarm	400°C

The following figure illustrates the relationships:








Figure 6 – Temperature monitoring

7.4.2 Average output level

Description	<p>This parameter is calculated during regular control operation.</p> <p>Note! After a set point change, the average output is temporarily deleted and recalculated. The output is also deleted if a zone is put into manual mode.</p>	
Parameter	<p>Zone parameter</p> <p> Average output level</p>	<p>Settings</p> <p>Is determined by the controller</p>
Procedure	<p>Start up the system. Let it work at the setpoint for approx. 10 minutes. Afterwards the determined value can be read in the zone parameter .</p>	

7.4.3 Broken sensor

Description	<p>A sensor break is automatically detected by the controller.</p> <p>In the event of a sensor break, the controller automatically switches over to the average output level. This sets the zone to manual mode and accepts the parameter  as the new output level. After the sensor break has been rectified, the zone automatically returns to control operation.</p> <p>The sensor break is shown as an alarm in the display.</p> <p>Note! If no average output was saved before the sensor break occurred, the zone switches off the corresponding output in case of an alarm.</p>
Example	<p>Zone 2 has a current setpoint of 110°C. According to parameter , the average output of the zone is 35%. In the event of a sudden sensor break, zone 2 would now be put into manual operation and 35% would be specified as the degree of operation.</p>

7.4.4 Heating current monitoring

Description	<p>The current flow to a heater can be continuously controlled by the heating current monitor.</p> <p>Current: Reference value To activate the heating current monitoring, the nominal current ("normal" current) of the heating element must be entered in Parameter <i>P14</i>. The current measurement monitors this value with the tolerance according to parameter <i>P15</i>.</p> <ul style="list-style-type: none"> • 0,0: no heating current monitoring • > 0: this value is monitored <p>Current: Tolerance Parameter <i>P15</i> defines the tolerance for heating current monitoring. The current measurement monitors the value of parameter <i>P14</i> with this tolerance.</p>	
Parameter	<p>Zone parameter</p> <p><i>P14</i> Current: Reference value</p> <p><i>P15</i> Current: Tolerance</p>	<p>Settings</p> <p>0,0...25,0A, Default value=0,0A</p> <p>0,0...16,0A, Default value=0,5A</p>


7.4.5 Triac monitoring

Description	<p>Each zone has its own triac monitoring (triac = electronic power switch which directly controls the heating circuits), in order to be able to detect a possible control interruption of a zone, e.g. nozzle heating. A defective triac is detected if a current flows without controlling the outputs.</p> <p>If a current flows, this zone is switched off and an error message $!tr$ is displayed.</p>
-------------	--

7.5 Special functions

7.5.1 BOOST

Description	<p>By executing the boost function, the temperature in selected zones is raised by a fixed value - the boost offset (parameter PiQ) - for a certain time (parameter PiI).</p> <p>The control is carried out via the "Boost button".</p>
-------------	---



Parameter	Zone parameter	Settings
	PiQ Boost-Offset	0...50K, Default value=0K
	PiI Boost-Duration	0...900s, Default value=60s

7.5.2 STANDBY

Description The use of the standby function is recommended in order to protect the tools and the raw material they contain as well as to reduce energy costs during downtimes. The standby temperature can be set according to the materials used.

It is controlled via the "Standby button". The standby function always applies to all zones.



Parameter	Zone parameter	Settings
	<i>P16</i> Standby temperature	0...300°C Default value=20°C

7.5.3 Load detection

Description With this parameter the load detection of the controller can be deactivated. This allows error-free control of very small nozzles with heating currents < 100 mA.

1 = Deactivate load detection

Parameter	Zone parameter	Settings
	<i>P17</i> Load detection	0, 1 Default value: 0

7.5.4 Default parameter

Description **System parameter *Std***
With this parameter a reset of all settings to the factory setting can be initiated.

1 = Load default parameters

Parameter	System parameter	Settings
	<i>Std</i> Default parameter	0, 1 Default value: 0

8 Parameter overview

8.1 Zone parameter

	Zone parameter	Short description	Chapter
<i>P01</i>	Lo-Alarm	Lower temperature limit value / under-temperature	7.4.1
<i>P02</i>	Hi-Alarm	Upper temperature limit value / excess temperature	7.4.1
<i>P03</i>	dL/dH-Tolerance band	Permitted deviation of actual temperature from setpoint	7.4.1
<i>P04</i>	P-Band	Parameter of the PID-Controller	7.2.1
<i>P05</i>	Tn Reset time	Parameter of the PID-Controller	7.2.1
<i>P06</i>	Tv Derivative time	Parameter of the PID-Controller	7.2.1
<i>P07</i>	Classification	Activate / deactivate classification	7.2.1
<i>P08</i>	Softstart	Gentle heating due to limitation of output	7.3.1
<i>P09</i>	Compound heating	Common, slow heating of zones	7.3.2
<i>P10</i>	Boost-Offset	Brief increase of the target temperature	7.5.1
<i>P11</i>	Boost-Duration	Time of temperature rise at BOOST	7.5.1
<i>P12</i>	Maximal output level	Output level limitation to maximum value	7.2.3
<i>P13</i>	Output level	Output presetting in manual operation	7.2.2
<i>P14</i>	Current reference value	Nominal current of the zone to be monitored	7.4.4
<i>P15</i>	Current tolerance	Tolerance of current monitoring	7.4.4
<i>P16</i>	Standby temperature	Lowering the temperature to a new set point	7.5.2
<i>P17</i>	Load detection	Switching off the load detection for error-free control of very small nozzles	7.5.3
<i>01</i>	Average output level	The average output level (Read Only)	7.4.2
<i>02</i>	Classification of zone	Found classification (Read Only)	7.2.1

8.2 System parameter

Display		System parameter	Short description	Chapter
<i>SYS</i> <i>Inf</i>	<i>SC</i>	Slowest channel	The slowest zone during heating is stored here	7.3.2
<i>SYS</i> <i>PAR</i>	<i>HH</i>	HH-Alarm	Shut-off temperature: Maximum upper temperature limit value for all zones	7.4.1
<i>SYS</i> <i>PAR</i>	<i>Δt</i>	Max temperature difference of the compound	Maximum temperature deviation of the compound heating	7.3.2
<i>SYS</i> <i>PAR</i>	<i>FAH</i>	Fahrenheit display	Presentation of the display	7.1.2
<i>SYS</i> <i>PAR</i>	<i>tEt</i>	Thermocouple type	Type of the connected thermocouples	7.1.3
<i>SYS</i> <i>PAR</i>	<i>IdL</i>	ID Level	User level	7.1.1
<i>SYS</i> <i>PAR</i>	<i>Code</i>	ID Code	Password	7.1.1
<i>SYS</i> <i>Inf</i>	<i>Pin</i>	Pin Code	The displayed value is required if the password has been forgotten. In this case contact the service	7.1.1
<i>SYS</i> <i>Fun</i>	<i>Std</i>	Default parameter	Reset to factory settings	7.5.3
<i>SYS</i> <i>Fun</i>	<i>SEr</i>	Service	Internal parameter for device maintenance	
<i>Id</i> <i>Inf</i>	<i>UEr</i>	Software Version	Shows the current software version of the power card	
<i>Id</i> <i>Inf</i>	<i>ttr</i>	Temperature heat sink	Shows the current temperature of the heat sink of the power card inside the case	
<i>Id</i> <i>Inf</i>	<i>ttc</i>	Temperature Thermo-Terminal	Shows the current temperature of the thermocouple terminal on the power card	
<i>SYS</i> <i>Inf</i>	<i>UEr</i>	Software Version	Shows the current software version of the firmware	

9 Technical data

EWIKON Heißkanalsysteme GmbH	pro CONTROL BASIC		
Number of zones	2	6	12
Housing			
Dimensions W x H x D	175 x 270 390 mm ^{*1}		205 x 275 x 390 mm ^{*1}
Weight	13kg		15kg
Body material	Galvanized steel		
Protection class	IP 20		
Environmental conditions			
Operating temperature	0...50°C		
Maximum housing surface temperature ^{*2}	55°C		
Air humidity	0...90% rel. Humidity, no condensation		
Storage temperature	-25 ... +75°C		
Operation and display			
Display per zone	2x three-digit 7-segment		
Control panel	12 Soft keys		
Electrical connection			
Connection cable with CEE plug	1 x 16 A	3 x 16 A	3 x 32 A
Supply voltage	3 x 190 – 400 V AC, N, PE		
Switchable to	3 x 110 – 230 V AC, PE		
Tolerance	+ 5% / -15%		
Main switch	40 A 3-pole		
Mains fuses			
Control voltage electronics	1 x 2,5A mid-term contracts (5 x 20mm)		
Internal heating outputs	per zone 16A gRL (6,3 x 32mm)		
Additional fuses (delta) internal	per zone 16A slow (6,3 x 32mm)		
Power consumption	max 30 W without load		
Thermocouple inputs			
Thermocouple	Fe-CuNi Typ J - 0...700°C		
convertible to	NiCr-Ni Typ K		
Cold junction compensation	Internal		
Measurement accuracy	±0,25 K		
Temperature query	4x128 / second		
Load outputs	Bistable, electrically insulated		
per zone	1x heating, 230VAC switchable		
Shortest controller response	10ms at 50Hz		
Current per zone	max. 16A at 80% Duty cycle		
Beware! Observe the total load capacity of the electrical connecting cable			
Minimum load	100 W		
Control behavior	PI, PD or PID separately adjustable for all zones		
Message contact/ control input			
Notification contact (relay contact) - potential-free			
Maximum voltage	250V AC		
Maximum current	4A at cosφ = 1; 2A at cosφ = 0,5		
Digital input - isol. potential free	13 – 30V DC		

^{*1}: Depth gauge without mold connection

^{*2}: at an air temperature of 20°C

10 Spare parts + accessories

The following table contains a useful list of spare parts that can be replaced if necessary, taking into account the safety instructions:

Spare parts	Order number
Control fuse	62-00012
Control zone protection 16A gRL	62-00087
Power card incl. heat sink and triacs	BP-12231C
Message contact / digital input cable	AU-00209
Triac 16A	05-00019

11 Appendix

11.1 Terminal bridges of the star-delta supply

11.1.1 Terminal jumpers in star network (state at delivery!)




Figure 7 - Star-network

11.1.2 Terminal bridges in delta network




Figure 8 - Delta-network

11.2 Notification contact / Digital input

Contact	Function	
1.+3.	Notification contact	Normally closed
2.	Digital input	0V Standby
6.	Digital input	24V Standby



We hereby confirm that the products described below conform to the essential protection requirements of the following European Directives

2014/35/EC “Low Voltage Directive”

and

2014/30/EC “EMC Directive”

with respect to their design type. This requires that the products are used for their intended purpose, that the assembly and operating instructions are observed and that genuine connecting cables outside the device are used.

Alterations made to the product will void the declaration of conformity.

Producer: EWIKON Heißkanalsysteme GmbH
Siegener Straße 35
35066 Frankenberg / Germany
phone: +49 (0) 6451 / 501-0

Product: **pro CONTROL hot runner controllers
for the operation of 230 V hot runner systems**

Type: Controllers for
2 / 6 / 12 zones
69400.002 / .006 / .012

Controllers for
6 / 12 zones
69510.006 / .012
69511.006 / .012

Controllers for
18 / 24 zones
69520.018 / .024
69521.018 / .024

Controllers for
30 / 36 zones
69530.030 / .036
69531.030 / .036

Controllers for
36 - 120 zones
69550.036 - .120
69551.036 - .120

Applied harmonised standards:

DIN EN 61010-1:2020-03

Safety requirements for electrical equipment for measurement, control and laboratory use

DIN EN 61326-1:2013-07

Electrical equipment for measurement, control and laboratory use - EMC requirements

Frankenberg, 30 October 2023



Dr. Stefan Eimeke
Managing Director

EWIKON
Heißkanalsysteme GmbH
Siegener Straße 35
35066 Frankenberg
Tel: +49 6451 / 501-0
Fax: +49 6451 / 501 202
E-mail: info@ewikon.com
www.ewikon.com

Item no.: 18406E All rights reserved including errors and content and technical changes. EWIKON 11/2023

EWIKON